


QWIK TUNE®




QT-11 Instructions

- For electric guitars, insert cable into “IN” jack. For acoustic guitars, hold the guitar so the sound hole is within 4-8 inches (100-200mm) of the “MIC” hole on the front of tuner.
- Press **ON**.
- Strike any string. The string being tuned will show at the top of the LCD meter.
- While tuning, if the needle stops to the left of “0” the pitch of the string is flat (♭). Increase tension on the string. Strike the string again. Repeat until the meter needle lines up directly over the “0” on the meter. The string is then in tune.
- If the needle stops to the right of the “0” the pitch of the string is sharp (#). Decrease string tension. Strike the string again. Repeat until the meter needle lines up directly over the “0” on the meter.
- The 3 LED's will light as follows:
 - **RED** ◀ The string is -1 to -80 cents below correct pitch.
 - **GREEN** ● The string is in tune.
 - **RED** ▶ The string is +1 to +80 cents above correct pitch.



- If the ◀ LED lights, follow instructions in no. 4 above.
If the ▶ LED lights, follow instructions in no. 5 above.
7. If the string is greater than -80 or +80 cents from true pitch, tighten or loosen the string until one of the LED's lights up.
 8. The QWIK TUNE® is more sensitive and the meter is faster acting than some other guitar tuners. On some guitars the needle on the LCD meter may move rapidly from one reading to another. If this happens, try striking the guitar string more lightly. Also, when tuning an acoustic guitar, make sure there is no background noise in the room (voices, other musical instruments, radio, etc.)
 9. When LCD becomes faint, replace batteries with 2 AAA batteries.
 10. After 2 minutes of non use, QWIK TUNE® will automatically shut off to save battery power.
 11. The **ELECTRONIC PITCH PIPE** is activated by the small button to the left of the **ON/OFF** button. Press once and you will hear the Low E tone. Press again for A, D, G, B, and High E tones. Press again to turn off. These tones can be used as a tuning reference to tune severely out of tune strings.

Enjoy your music!



Get the Scoop on
the Latest in
Tuners & Metronomes!
www.qwiktunetuners.com

What's New in Guitars,
Effects & Accessories!
www.danelectro.com

EEC Agent: John Hornby Skewes & Co., Ltd.
Salem House, Parkinson Approach, Garforth, Leeds LS25 2HR UK

QWIK TUNE LIMITED U.S.A. WARRANTY

This product is warranted to the original purchaser to be free from defects in material and workmanship for a period of 12 months from the date of purchase, provided you provide proof of purchase at the time of requesting warranty service. In the event of defect we will, at our option, repair or replace the defective product with a new or reconditioned product, provided the defective product is returned beforehand postage and insurance prepaid to Evets Corporation at the address below. This warranty does not cover batteries, casings, or damage caused by accident or misuse. Warranty valid in the USA. This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Please retain a copy of this warranty and your sales receipt.

EVETS CORPORATION
P.O. Box 1327,
Camarillo, CA 93011
Telephone: (805) 389-4605
Fax: (805) 383-2050

This product complies with FCC Part 15 rules. Operation of this product is permitted in USA provided this product does not cause harmful interference and provided this product accepts interference from other devices, even if that interference is detrimental to performance of this product.